



EFEL STARTGENERATOR




GENERATOR DATA



Typ 4-06



Typ 4-07



VÄNSTER-MONTERING

HÖGER-MONTERING

4-06000
4-07000

4-06030
4-07030

